

Time setting by using NTP

If the camera does not playback properly, please check the camera time setting correct or not,

Please use NTP to set to your local time, sync with your own time zone as below pic.

The screenshot displays the 'Configuration' page of a camera's web interface, specifically the 'Date & Time' settings. The interface is dark-themed with a sidebar on the left containing navigation options: Camera, Network, PTZ, Event, Storage, System (highlighted), and Information. The 'System' menu includes options like Users Manage, Device Language, Factory Reset, Reboot, Auto Maintain, and Upgrade. The main content area shows the following settings:

- Update Method:** NTP (highlighted with a red box)
- Time Zone:** GMT+08:00
- NTP Server:** pool.ntp.org
- Port:** 123 (with a range of 1-65535)
- Update Period:** 1 Minutes (with a range of 1-16666)
- Current Time:** 2019 - 08 - 19 10 : 39 : 31
- Enable DST:**

At the bottom of the settings area, there are three buttons: 'Reset Defaults', 'Refresh', and 'Save'. A yellow arrow points to the 'Save' button.