


Step 1

Log on Camera and create your Verification code.



The screenshot shows the 'Configuration' tab of a camera's web interface. The 'Platform Access' sub-tab is selected and highlighted with a red box. The 'Enable' checkbox is checked. The 'Platform Access Mode' is set to 'Guarding Vision'. The 'Server IP' is 'dev.sgp.guardingvision.com'. The 'Register Status' is 'Online'. The 'Verification Code' field contains six dots, with a red arrow pointing to it and the text 'Create Your own here please'. A 'Save' button is visible at the bottom.

Configuration

SNMP FTP Email **Platform Access** HTTPS QoS 802.1x Integration Protocol

Enable

Platform Access Mode: Guarding Vision

Server IP: dev.sgp.guardingvision.com Custom

Register Status: Online

Verification Code: ●●●●●●


6 to 12 letters (a to z, A to Z) or numbers (0 to 9), case sensitive. You are recommended to use a combination of no less than 8 letters or numbers.

Create Your own here please

Save

Step 2

Add camera to Hik-connect (Guarding vision) App, active remote control.



The screenshot shows the 'Online Device' screen in the Hik-connect app. The title bar is red with a white back arrow and the text 'Online Device' in a yellow box. The status bar at the top shows '中国电信', signal strength, Wi-Fi, time '11:37', and battery '55%'. The list contains three devices:

Device Type	IP Address	Status
DS-7608NI-E2/8P	192.168.1.130	Completed.
DS-7616NI-I2/16P	192.168.1.33	Completed.
	192.168.1.134	Active

The third device, with IP 192.168.1.134 and status 'Active', is highlighted with a green box.

